


Installation Recommendations

1. The HDL DV6 is designed to fit underneath the slating battens. It is therefore recommended that whether used in either new or refurbishment work, the gable brickwork be constructed or prepared to allow flat and even contact surface for the Dry Verge.


2. With the slating battens already fitted, commence fitting the Dry Verge from ridge to eaves. The horizontal flange of this profile should be inserted underneath the batten and roofing underlay, then fixed by nailing through the batten and profile into the gable masonry using suitable masonry nails of an acceptable quality at 500mm centres maximum. The roofing underlay should be trimmed into the channel of the verge profile.

3. When joining sections of Dry Verge it is essential to interlock the upper section into that of the next lower section allowing approximately 150mm overlap for in-line joints.


Ridge Joints: The verges are cut with a vertical mitre and butt jointed. A lead or lead replacement saddle may be fitted under or over the joint if required. The ridge tile should be trimmed if necessary to suit, or a block end ridge tile used.



Verge Joints: Where the joints in the verge are required along the edge of the roof, they should be overlapped with the lower section fitted over/around the upper section.



Sprocket Joints: Slight or gentle sprockets can easily be accommodated by cutting the lower section to a slight rake and fitting over the main verge section.



Typical Installation Detail

