







Interlocking Tile Verge System Components




Dry Verge Unit
(Code: HD MV20/L)
10 per pack




Dry Verge Unit
(Code: HD MV20/R)
10 per pack




Half Round End Cap
(Code: HD IPTDV/HR)
Also available in Angle End Cap
(Code: HD IPTDV/AR)



Angle Ridge End Cap
(Code: HD IPTDV/AR)
Also available



Starter Unit Kit
(Code: HD IPTDV/ST)
2 per pack



Batten End Clip
(Code: HD IPTDV/BC)
10 per pack

Hambleside Danelaw Limited

Long March, Daventry, Northamptonshire NN11 4NR


Tel: 01327 701900 | Email: techelp@hambleside-danelaw.co.uk | www.hambleside-danelaw.co.uk

HD_MidVerg20_InstallRecVs1_Jul24


Hambleside Danelaw
Building Products




Installation Recommendations




1. The tile battens should be fixed as required and in accordance with the tile manufacturer's instructions leaving a 35 to 40mm overhang beyond the face of the masonry or barge board creating a gap of 5mm or so between the verge unit and the wall or barge board. The underlay should be trimmed to extend 5mm beyond the ends of the battens.




2. It is recommended that batten end clips (code: HD IDV/BC) or a suitable screw should be used at the batten ends to provide long term secure fixing and wind load resistance to comply with BS 8612. One clip should be nailed twice to the top of each batten with the short flange in contact with the batten end.




3. The verge starter unit (code: HD IPTDV/ST) should be fixed securely at the eaves through the slots using the 2 x 25mm flange head screws provided into the barge board or masonry. The starter unit is most easily marked for position by fitting to a verge unit and placing the verge unit onto the eaves tile.




4. Next, clip the first verge unit on to the starter unit. Once securely clipped, the verge unit can then be nailed or screwed through one of the holes provided into the batten end. Where the batten end clip is used, the nail should penetrate one of the slots provided.



5. Subsequent units are fitted in the same way, clipping each verge unit over the previously fixed unit up to the ridge ensuring that each verge unit is pushed up-slope to fit snugly onto the tile. A small gap of a few millimetres should be maintained between the underside of the dry verge units and the masonry or barge board.



6. When using third-round ridge tiles, the 'HR' ridge end cap (code: HD IPTDV/HR) may be fitted to the ridge tile, interlocking with the verge units and then fixed into the barge board or masonry through the blind holes using the two 65mm screws provided. Extra fixings may be required to secure the ridge cap when used on steep roof pitches.



7. Alternatively, a block end ridge tile may be used to complete the installation, fitted in accordance with the tile manufacturer's recommendations. For roof pitches above 50° a block end ridge tile should be used.

